



Box 18093 Austin, TX 78760

(512) 451-5874

### CP-ZX VERY SMART CENTRONICS INTERFACE FOR ZX-81, TS1000

1. Automatically sets RAMTOP to the correct value in systems larger than 16K.
2. Automatically boots AERCO disc system. Holding the SPACE key depressed when power is applied or the RESET button pressed will defeat the AutoBoot process.
3. Software selection is provided for the following functions. Control is exercised by POKEing the System Variable VERSN located at 16393 Decimal (4009 Hex) with the sum of the values for the various functions. The value of this byte is normally Zero, which sets the default functions when the system is turned on.

**VALUE 1:** Not yet implemented.

**VALUE 2:** Disables automatic Linefeed after Carriage Return. If your printer is double-spacing, this value should be 2. If your printer puts everything on the same line, this value should be 0.

**VALUE 4:** Disables Centronics printer.

**VALUE 8:** Enables 2040 printer.

**VALUE 16:** Disables Memotech software control characters. Memotech interfaces use an inverse period to preface control characters. The default value of this feature needs to be ON to properly service certain software packages. You can usually just ignore this function.

<b>EXAMPLE:</b> Send Line Feed after Carriage Return	0
Enable Centronics printer	0
Enable 2040 printer	8
Disable Memotech control characters	16
	<hr/>
	24

Select the above list of features with POKE 16393, 24